


FEET

SIDE FRAME

TOP FRAME

PLATE POST


RK-2600 PLATE RACK



ASSEMBLY INSTRUCTIONS:

- 1. SLIDE THE TWO SIDE FRAMES (#3) ONTO THE TOP FRAME (#4), MAKING SÜRE THAT THE LARGE PLATE POST HOLES ARE FACING OUT. DO NOT PLACE BOLTS INTO POSITION, YET.
- 2. SLIDE THE TWO FEET (#2) IN THE BOTTOM FRAME (#1), MAKING SURE THAT THE LARGE PLATE POST HOLES ARE FACING UP. AGAIN, DO NOT PLACE BOLTS INTO POSITION, YET.
- 3. PULL FEET SLIGHTLY OUT FROM BOTTOM FRAME. PUSH SIDE FRAMES ONTO FEET WHILE ALLOWING FEET TO MOVE BACK INTO BOTTOM FRAME.
- 4. WHEN RACK LOOKS LIKE THE DRAWING. PLACE ALL BOLTS (#7) INTO POSITION. "SNUG" ALL BOLTS, THEN GO BACK AND TIGHTEN THEM.
- 5. PUSH PLATE POSTS INTO LARGE HOLES AND TIGHTEN WITH BOLTS. NOTE: PLATE POSTS POSITIONS CAN BE VARIED ACCORDING TO YOUR PREFERENCE.
- 6. SLIDE ON RUBBER WASHERS (#6).

EXPLODED DRAWING



info@ivankobarbell.com www.ivankobarbell.com